

Marca	Modelo	Serie
SEAT	Alhambra	Alhambra 2,8 V6
SEAT	Alhambra	Alhambra TDI 1,9
SEAT	Alhambra	Alhambra Turbodiesel 1.2 - 1.9i
SEAT	Arosa	Arosa TDI 1,2
SEAT	Arosa	Arosa TDI 1,4
SEAT	Cordoba	Cordoba 1,6i
SEAT	Cordoba	Cordoba CLXI, GLXI 1,4i, 1,6i
SEAT	Cordoba	Cordoba Diesel, Turbodiesel GLX 1,9
SEAT	Cordoba	Cordoba Diesel, Turbodiesel GLX 1,9
SEAT	Cordoba	Cordoba GLXI 1,8i
SEAT	Cordoba	Cordoba SDI 1,9
SEAT	Cordoba	Córdoba SE Diesel - Turbodiesel 1.9i
SEAT	Cordoba	Cordoba T 1,8
SEAT	Cordoba	Cordoba TDI 1,9
SEAT	Cordoba	Cordoba TDI 1,9
SEAT	Cordoba	Córdoba Vario Sdi - TD Intercooler 1.9i
SEAT	Ibiza	Ibiza 1,4
SEAT	Ibiza	Ibiza V 1,4 16v 85CV
SEAT	Ibiza	Ibiza V 1,6 16v 105CV
SEAT	Ibiza	Ibiza CLXI, GLXI 3 - 5 puertas 1,4i 1,6i
SEAT	Ibiza	Ibiza Diesel, Turbodiesel CL 3 - 5 puertas 1,9
SEAT	Ibiza	Ibiza GLXI, GTI 3 - 5 puertas 1,8i 2,0i
SEAT	Ibiza	Ibiza Latino 1.6i MP
SEAT	Ibiza	Ibiza Passion 1.0i MO
SEAT	Ibiza	Ibiza T Cupra 1.8 20V
SEAT	Ibiza	Ibiza TDI 1.4
SEAT	Ibiza	Ibiza TDI Cupra 1,9
SEAT	Ibiza	Ibiza TDI, SDI 1.4 - 1.9
SEAT	Ibiza	Ibiza TDI,SDI 1,9
SEAT	Ibiza II	Ibiza II 1.4i 16V - 1.6i
SEAT	Ibiza II	Ibiza II Diesel 1.9
SEAT	Ibiza II	Ibiza II GTi - GT 1.8i 16V - 2.0i
SEAT	Ibiza II	Ibiza II Turbodiesel 1.9
SEAT	Inca	Inca Diesel 1.9
SEAT	Inca	Inca Nafta
SEAT	Leon	Leon 2.0 TFSi
SEAT	Leon	Leon 1,6i
SEAT	Leon	Leon 1,6i
SEAT	Leon	Leon 1,8i 20V
SEAT	Leon	Leon 1,8i TFSi
SEAT	Leon	Leon cupra 4 1,9 TDI
SEAT	Leon	Leon 2,3i V5
SEAT	Leon	Leon 2,8 V6 cupra 4 1,9
SEAT	Leon	Leon BKC - BLS, HP105. AZV, HP 136. BKD, HP 140. BMM, BMN HP170.
SEAT	Leon	Leon TDI 2.0 TDI , BMN HP 170 KW 125
SEAT	Leon	Leon Diesel 2,0 TDI
SEAT	Leon	Leon Diesel 2,0 TDI
SEAT	Leon	Leon Diesel 2,0 TDI
SEAT	Leon	Leon SDI 1,9
SEAT	Leon II	Leon II 2,0 TDI
SEAT	Leon II	Leon TFSI, TFSI FR 1P1 BWJ HP 177, BWA HP 147
SEAT	Toledo	Toledo 1,6i
SEAT	Toledo	Toledo 1,8i 20V
SEAT	Toledo	Toledo 1,9 TDI
SEAT	Toledo	Toledo BMN HP 170.
SEAT	Toledo	Toledo 1.9 TDI, 2.0 TDI BJB, BKC, BLS HP 105. AZV HP 136. BKD, BMM HP 140.
SEAT	Toledo	Toledo Diesel GL, Turbodiesel GLX 1,9

Desde	Hasta	Aire	Habitaculo	Aceite	Combustible
2000-07-01	- en adelante			EOL110	
2000-07-01	- en adelante	-	-	EOL105	-
1993-03-01	- en adelante	AR399PM	-	OL456	-
1999-10-01	- en adelante	-	-	EOL110	-
1999-10-01	- en adelante	-	-	EOL110	-
1999-07-01	- en adelante	AR1643PM	TH901	OL490	IN1001
0000-00-00	- en adelante	AR1642PM	TH901	OL445	IN1001
0000-00-00	- en adelante	AR399PM	TH901	OL460	GS67
2000-04-07	- en adelante	AR399PM	TH901	OL456	-
0000-00-00	- en adelante	-	TH901	OL97V	IN1001
1999-07-01	- en adelante	AR1643PM	TH901	-	-
2000-04-08	- en adelante	AR399PM	TH901	OL456	-
1999-07-01	- en adelante	AR1643PM	TH901	-	IN1001
1999-07-01	- en adelante	AR1643PM	TH901	EOL105	-
2002-10-01	- en adelante	AR1667PMS	-	EOL110	-
2000-04-08	- en adelante	AR399PM	TH901	OL456	GS68
1999-01-01	- en adelante	AR1642PM	TH901	-	IN1001
2010-01-01	- en adelante	AR1748PM	TH947	OL445	-
2010-01-01	- en adelante	AR1748PM	TH947	-	-
1993-03-01	- en adelante	-	TH901	OL490	IN1001
1993-03-01	- en adelante	AR399PM	TH901	OL460	GS67
1993-03-01	- en adelante	-	TH901	OL97V	IN1001
2000-04-08	- en adelante	AR1642PM	TH901	OL97V	IN1001
2000-04-08	- en adelante	-	TH901	OL445	IN1001
2004-02-01	- en adelante	AR1667PMS	TH947	OL97V	IN1001
2005-06-01	- en adelante	AR1667PMS	-	EOL110	-
2004-05-01	- 2005-04-01	AR1667PMS	TH947	EOL110	GS219
2002-02-01	- en adelante	AR1667PMS	TH947	EOL110	-
1999-08-01	- en adelante	AR1643PM	TH901	EOL105	GS68
2000-04-07	- en adelante	-	TH901	OL445	IN1001
2000-04-07	- en adelante	AR399PM	TH901	OL456	GS67
2000-04-07	- en adelante	-	TH901	OL97V	IN1001
2000-04-07	- en adelante	AR399PM	TH901	-	-
1998-03-01	- en adelante	AR399PM	TH901	OL460	GS67
0000-00-00	- en adelante	AR399PM	-	OL97V	IN1004
2005-04-08	- en adelante	AR1678PM	THC959	EOL134	IN1005
2005-04-08	- en adelante	-	-	OL490	IN1005
1999-11-01	- 2000-12-01	AR1634PM	-	OL445	-
1999-11-01	- en adelante	AR1634PM	-	-	-
2007-04-08	- en adelante	-	THC959	-	IN1005
2001-01-01	- en adelante	AR1634PM	TH947	EOL105	-
1999-11-01	- en adelante	-	-	EOL110	-
2001-01-01	- en adelante	AR1634PM	TH947	EOL105	-
2005-01-08	- en adelante	AR1671PM	-	-	-
2006-01-01	- en adelante	AR1671PM	-	-	-
2000-04-08	- en adelante	AR1634PM	-	-	GS68
2005-04-08	- en adelante	AR1671PM	THC959	EOL110	EGSO201
2005-04-08	- en adelante	AR1671PM	THC959	EOL110	EGSO210
1999-08-01	- en adelante	AR1634PM	-	EOL105	-
2005-01-08	- en adelante	AR1678PM	THC959	EOL134	EGSO210
2006-01-11	- en adelante	AR1678PM	THC959	EOL134	-
1999-03-01	- 2000-12-01	AR1634PM	-	OL445	-
1999-03-01	- en adelante	AR1634PM	-	OL97V	-
1999-04-01	- en adelante	AR1634PM	TH947	EOL105	GS67
2006-01-01	- en adelante	AR1671PM	-	-	-
2004-01-11	- en adelante	AR1671PM	-	-	-
0000-00-00	- en adelante	AR399PM	-	OL460	GS67

Marca	Modelo	Serie
SEAT	Toledo	Toledo FSI 5P2 2.0 BLR, BLY, BVY, BVZ HP 110
SEAT	Toledo	Toledo GLXI 1,8i
SEAT	Toledo	Toledo GLXI 2,0i
SEAT	Toledo	Toledo III 2.0 TDI
SEAT	Toledo	Toledo III 2.0 TDI
SEAT	Toledo	Toledo Magnus 1.6i
SEAT	Toledo	Toledo Magnus Diesel - Turbodiesel 1.9
SEAT	Toledo	Toledo T. FSI 5P2 2.0 Turbo AXX, BWA HP 147
SEAT	Toledo	Toledo VR5 2,3

Desde	Hasta	Aire	Habitaculo	Aceite	Combustible
2004-01-11	- en adelante	-	-	EOL134	-
0000-00-00	- en adelante	-	-	OL97V	IN88
0000-00-00	- en adelante	-	-	OL97V	IN88
2004-11-07	- en adelante	AR1671PM	THC959	EOL110	EGSO201
2004-11-07	- en adelante	AR1671PM	THC959	EOL110	EGSO210
2000-04-07	- en adelante	AR399PM	-	-	IN88
2000-04-07	- en adelante	AR399PM	-	OL456	GS67
2006-01-05	- en adelante	-	-	EOL134	-
1999-04-01	- en adelante	AR1634PM	TH947	EOL110	-