

Marca	Modelo	Serie	Desde	Hasta	Aire	Habitaculo	Aceite	Combustible
SKODA	Fabia	Fabia 1,9 SDI	1999-08-01	- en adelante			EOL105	
SKODA	Fabia	Fabia 2	2000-11-01	- en adelante	AR1667PMS	-	OL97V	-
SKODA	Fabia	Fabia 1,9 TDI	1999-09-01	- en adelante	AR1667PMS	-	EOL110	GS219
SKODA	Fabia	Fabia Diesel 1,9	2000-01-01	- en adelante	AR1667PMS	-	-	GS59
SKODA	Fenicia	Felicia Diesel 1,9	1995-11-01	- en adelante	AR399PM	-	OL460	GS67
SKODA	Fenicia	Felicia GLX 1,3	2000-04-02	- en adelante	-	-	OL84M	TN3
SKODA	Fenicia	Felicia SLX 1,6i	1995-09-01	- en adelante	AR399PM	-	-	IN1004
SKODA	Octavia	Octavia 1,6 I	1997-05-01	- 2000-11-01	AR1634PM	TH947	-	-
SKODA	Octavia	Octavia 1,9 SDI	1996-09-01	- en adelante	AR1634PM	-	EOL105	-
SKODA	Octavia	Octavia 1,9 TDI	1997-09-01	- en adelante	AR1634PM	TH947	EOL105	-
SKODA	Octavia	Octavia 2,0i	1999-04-01	- en adelante	AR1634PM	-	-	-
SKODA	Octavia	Octavia BJB, BKC, BLS - AZV, BKD HP 140 1.9 - 2.0TDI	2004-01-05	- en adelante	AR1671PM	-	-	-
SKODA	Octavia	Octavia T 1,8	1997-08-01	- en adelante	AR1634PM	-	-	-
SKODA	Octavia	Octavia SLX 1,8i 20V	1996-09-01	- en adelante	AR1634PM	-	-	-
SKODA	Superb	Superb 1,8 20V Turbo	2001-09-09	- en adelante	AR1639PM	-	-	-
SKODA	Superb	Superb 1,9 TDI	2002-06-01	- en adelante	AR1639PM	-	EOL105	-
SKODA	Superb	Superb 2.0	2001-09-09	- en adelante	AR1639PM	-	-	-
SKODA	Superb	Superb 2,8 V6	2001-09-09	- en adelante	AR1639PM	-	-	-